

02 — Replication & Improvement (DenseNet121)

1. Objective of This Phase

After establishing a ResNet18 baseline, the next objective was to:

1. Replicate a commonly used architecture in knee OA literature
2. Compare its performance to the baseline
3. Improve the architecture through justified modifications

Professor this phase aligns directly with your requirement:

“Find related works, replicate one approach, and improve upon it.”

2. Literature-Informed Architecture Selection

DenseNet121 was selected for replication because:

- It is widely used in medical imaging tasks.
- It has demonstrated strong performance in knee OA grading literature.
- Dense connectivity improves feature reuse and gradient flow.
- It performs well on fine-grained classification problems.

DenseNet architectures are commonly reported in KL grading studies for their ability to capture subtle texture variations in joint space narrowing and osteophyte formation.

3. Replication Phase — DenseNet121 @ 224×224

3.1 Model Configuration

- Backbone: DenseNet121 (ImageNet pretrained)
- Input resolution: 224×224
- Final classifier replaced with 5-class output
- Transfer learning applied

Two-stage training:

1. Train classifier head
 2. Fine-tune final dense blocks
-

3.2 Training Setup

- Optimizer: Adam
 - Initial learning rate: $1e-3$ (head), $1e-4$ (fine-tuning)
 - Weight decay: $1e-4$
 - Scheduler: ReduceLROnPlateau
 - Loss: CrossEntropy
 - Class imbalance handled via WeightedRandomSampler
-

3.3 Replication Results (224 Resolution)

Test Performance:

- Accuracy ≈ 0.56
- Macro-F1 ≈ 0.58

Observation:

- Performance did not exceed ResNet baseline.
- DenseNet required stronger tuning.
- Adjacent KL confusion persisted.

This demonstrates that simply switching architecture does not guarantee improvement.

4. Improvement Strategy

Instead of arbitrary hyperparameter tuning, improvements were based on domain reasoning.

Radiographic KL grading relies heavily on:

- Subtle joint space narrowing
- Small osteophytes
- Fine texture differences

These features may not be well captured at 224×224 resolution.

Therefore, the improvement hypothesis was:

Increasing image resolution should allow better preservation of fine anatomical details and improve classification performance.

5. Final Improvement — DenseNet121 @ 320×320

5.1 Changes Introduced

- Increased input resolution to **320×320**
- Maintained DenseNet121 backbone
- Fine-tuned deeper dense blocks
- Used WeightedRandomSampler
- Adjusted batch size to accommodate GPU memory

No architectural changes beyond resolution and structured fine-tuning.

5.2 Final Model Configuration

- Backbone: DenseNet121
- Resolution: 320×320
- Optimizer: Adam
- LR (fine-tune): 1e-4
- Weight decay: 1e-4
- Scheduler: ReduceLROnPlateau
- Training epochs: 12

Hardware:

- GPU: Tesla T4
-

6. Final Results — DenseNet121 (320 Resolution)

Test Performance:

- **Accuracy ≈ 0.645**
- **Macro-F1 ≈ 0.654**

Per-class behavior:

- KL 0: Strong performance
- KL 3: High recall and precision

- KL 4: High F1 (severe OA detected reliably)
- KL 1 remains challenging
- Most confusion occurs between adjacent KL grades

This represents a clear improvement over:

- ResNet18 baseline
- DenseNet121 @224 replication

7. Comparative Summary

Model	Resolution	Test Accuracy	Macro-F1
ResNet18	224	~0.59	~0.62
DenseNet121 (replication)	224	~0.56	~0.58
DenseNet121 (improved)	320	~0.645	~0.654

Key Insight:

Resolution plays a critical role in fine-grained KL grading tasks.

8. Analysis of Improvement

The performance gain suggests:

- Dense connectivity benefits from higher-resolution features.
- KL grading requires fine structural details.
- Resolution scaling is more impactful than shallow architectural swaps.

The improvement was achieved without introducing complex ensembling or heavy augmentation, maintaining model interpretability and reproducibility.

9. Conclusion of Replication & Improvement Phase

This phase successfully demonstrates:

- Literature-informed replication
- Structured improvement
- Quantitative gain over baseline

- A defensible methodological progression

DenseNet121 at 320×320 is selected as the model used for interpretability analysis (Grad-CAM).